

## Wiring for MB electrical switches and looms

### AC Ignition switch MB, Kace, Mega type also MB DC ignition switch uses same colours

<b>IGNITION SWITCH</b>		<b>JUNCTION BOX (bulb holder)</b>
pink	-	earth point
Blue	-	grey or Purple
Orange	-	Orange
Yellow	-	Yellow
Green	-	Green
Black	-	Black
Brown	-	Brown

(spare wire could go to horn if there is not already a power feed or blank it off)

### MB Electronic looms or copies of it

<b>MB ELECTRONIC LOOM</b>		<b>JUNCTION BOX (bulb holder)</b>
Green	-	Green
Black	-	Black
Brown (with short grey)	-	Brown
short grey	-	grey or Purple

### Li style light switch, POLISHED type

<b>LIGHT SWITCH</b>		<b>JUNCTION BOX (bulb holder)</b>	
Yellow	-	Orange	
Blue	-	Blue	
Red	-	Red	
White	-	White	needs extending down to horn
Black	-	Black	
Brown	-	Orange	
Purple	-	Yellow	
Green	-	Brown	

### If using with an ignition switch only use these wires, disconnect and blank the others

<b>LIGHT SWITCH</b>		<b>JUNCTION BOX (bulb holder)</b>	
Yellow	-	Orange	
Blue	-	Blue	
Red	-	Red	
White	-	White	needs extending down to horn
Black	-	blank off	
Brown	-	blank off	
Purple	-	blank off	
Green	-	blank off	

**Li style light switch, CHROME type**

<b>LIGHT SWITCH</b>		<b>JUNCTION BOX (bulb holder)</b>
Orange	-	Orange
Blue	-	Blue
Red	-	Red
White	-	White
White/Black	-	Black
Green/Black	-	Brown
Red/Black	-	Yellow
Blue/Black	-	Orange

**If using with an ignition switch only, use these wires, disconnect and blank the others**

<b>LIGHT SWITCH</b>		<b>JUNCTION BOX (bulb holder)</b>	
Orange	-	Orange	
Blue	-	Blue	
Red	-	Red	
White	-	White	needs extending down to horn
White/Black	-	blank off	
Green/Black	-	blank off	
Red/Black	-	blank off	
Blue/Black	-	blank off	

**Gp / Sx / Tv dip / dazzle switch**

<b>LIGHT SWITCH</b>		<b>JUNCTION BOX (bulb holder)</b>
Yellow	-	Orange
Blue	-	Blue
Red	-	Red
White	-	White